



**INTERCON**  
FURNITURE FOR LIFE

# ASSEMBLY INSTRUCTIONS


DESCRIP: BACKLESS BENCH, COUNTER HEIGHT

ITEM: DK-BS-1566B-RFO-K24


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Please keep all hardware out of reach of small children.

1  BENCH TOP (x1)	2  LEG FRAME- LEFT (x1)	3  LEG FRAME- RIGHT (x1)	4  MOUNTING PLATE (x2)	5  CENTER RAIL (x1)	6  BASE CAP (x1)	7  METAL BAR (x1)	
A  BOLT 1/4" x 2 5/16" (x4)	B  BOLT 5/16" x 1 3/4" (x16)	C  SPRING WASHER 5/16" (x16)	D  FLAT WASHER 5/16" (x16)	E  SPRING WASHER 1/4" (x4)	F  FLAT WASHER 1/4" (x4)	G  ALLEN KEY M4 (x1)	H  WRENCH (x1)


## STEP 1




## STEP 2



## STEP 3



## STEP 4



COMPLETE ASSEMBLY

### ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast and easy assembly.

### ⚠ WARNING

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.